

## Attachment L

### Vapor Recovery Tests for Phase I Underground Storage Tanks and Balance Phase II EVR Systems (HIRT VCS 100 Processor-MCAS Miramar)

Phase I EVR Executive Orders VR-101-X, VR-102-X, VR-103-X, VR 104-X, VR-105-X. Phase II EVR Executive Orders VR-204-X

Unless otherwise specified by a District representative, the tests noted in the table below shall be conducted in the following order. The order is specified to not bias any test(s) and for practicality purposes.

Test Order	Test	Notes
1	HIRT Processor Panel Operability (Exhibit 8)	<b>Phase II</b>
2	TP 201.1E P/V Vent Valve Test	<b>Phase I</b>
3	TP 201.1B Static Torque of Rotatable Phase I Adaptors	<b>Phase I</b>
4	TP 201.1C/D Pressure Integrity Check Drop Tube/Drain Valve	<b>Phase I</b>
5	Exhibit.11 Incon ISD System Vapor Pressure Sensor Verification Test	<b>Phase II.</b> This test can be conducted during the pressure decay test. The vapor space shall be pressurized to 2.0" WC.
6	Exhibit 7 (Nozzle Bag Test)	<b>Phase II.</b> This test can be conducted during the pressure decay test. The vapor space shall be pressurized to 2.0" WC.
7	TP 96-1 Ten Inch Pressure Decay or TP 201.3 Two Inch Pressure Decay	<p><b>Phase I/II.</b> TP 201.3 shall be conducted and completed between sundown and a half hour after sunrise. TP 96-1 can be conducted at any time except when daytime temperatures exceed 100°F and there is direct sunlight on exposed metal vent pipe(s) and metal manhole cover(s) that are in contact with vapor space of the storage tanks.</p> <p>Exhibit 4 (Required items) of EO VR 203/204 must be conducted in conjunction with either TP 201.3 or 96-1.</p> <p>If nitrogen is introduced through the vapor adaptor, the vapor coupler test assembly shall be leak checked in accordance with TP 201.3 (sections 5.5, 6.7-6.7.2) prior to conducting the TP 96-1 test.</p> <p>The submersible fuel pumps shall be turned off prior to conducting the TP 96-1 test.</p> <p>All P/V valves are to be removed and vent risers capped prior to conducting TP 96-1 test. The valves are to be reinstalled and vent risers un capped after the test is complete.</p>
8	Exhibit 5 Liquid Removal Option 1 Pre EVR Balance Systems TP 201.6C Option 1 (Exhibits 8c, 9c, 10, 11 of EO G-70-52-AM)	<b>Phase II.</b> Must conduct flow rate verification for each grade point prior to starting liquid removal test. The flow rates for all grade points must be tested and verified to be with the range of 6.0-10.0 gallons per minute (gpm). A minimum of one gallon of gasoline must be dispensed when measuring flowrate. If the flowrate is determined to be outside of 6.0-10.0 gpm during the initial flow rate screening that grade point must be retested by timing for a minimum of 30 seconds.
9	TP 201. 4 Dynamic Back Pressure Methodology 1	<b>Phase II.</b> Exhibit 6 (Required items) of EO VR 204-X must be conducted in conjunction with TP 201.4
10	Exhibit 10 Incon ISD Vapor Flow Meter Operability Test	<b>Phase II.</b> If ISD is installed at the facility. EO 208-A

## Attachment L-1- HIRT VCS 100 Processor-MCAS Miramar ISD Alarm Response Requirements and Instructions

Alarm conditions shall not be cleared unless at a minimum the applicable troubleshooting tests and/or inspections listed have been conducted to clear the alarm condition. Other tests and/or inspections may be performed in lieu of those cited below provided the same ISD alarm does not occur within the next consecutive assessment period after resetting the alarm. Unless otherwise specified alarms conditions should only be cleared by person(s) that have the applicable certification/training as specified in Attachment K-Certification Requirements. All alarms and associated repairs and testing including inspection results shall be recorded in Attachment I-Inspection, Maintenance and Alarm Response log and made available to the District upon request.

Troubleshooting Tests and Inspections also include, but are not limited to, the lists referenced in the Incon Vapor Recovery Monitoring Troubleshooting and Diagnostics Guide.

Alarm Condition- ISD Display Message	Indicator Light and Alarm Condition	Alarm Response	Tests/Inspections
<b>Vapor Leak Alarm</b> <b>Incon-Weekly Ullage Pressure Leak Test Warning</b>	<b>Yellow</b> –Leak alarm warning. Alarm will go to failure after 7 days.	Contact certified technician and inform of alarm warning condition. <b>This alarm must be cleared by a certified technician</b> unless the ISD self clears. Record alarm condition and any tests/repairs in Attachment I.	TP-201.1E- P/V Valve TP-201.1C or TP-201.1D-Drop Tube integrity test TP-96-1- 10 inch Pressure Decay VR 204-X Exhibit 10, 13 Inspect boots for damage
<b>Vapor Leak Alarm</b> <b>Incon-Weekly Ullage Pressure Leak Test Failure</b>	<b>Red</b> – Leak alarm failure on 8 <sup>th</sup> day after 7 day warning alarm	<b>This alarm must be cleared by a certified technician only.</b> Contact certified technician and inform of alarm failure condition. The technician must perform all repairs and testing prior to clearing the alarm condition. Record alarm condition and any tests/repairs in Attachment I.	

Alarm Condition- ISD Display Message	Indicator Light and Alarm Condition	Alarm Response	Tests/Inspections
<b>Pressure Alarm (Overpressure)</b> <b>Veeder Root</b> -ISD Gross Pressure Warning <b>Incon</b> -Weekly Ullage Pressure Warning	<b>Yellow</b> —Gross overpressure alarm warning. Alarm will go to failure after 7 days.	<p>Per ARB Advisory 405-D. Operators can clear these alarms (without repairs or testing) <b>only</b> during the winter months from November 1-March 31<sup>st</sup>. The advisory remains in effect until formally rescinded by ARB. Record alarm condition in Attachment I.</p> <p><b>This alarm must be cleared by a certified technician</b> from April 1-October 31.</p> <p><b>Warning alarm</b> Contact certified technician and inform of alarm warning condition. This alarm must be cleared by a certified technician unless the ISD self clears.</p> <p><b>Failure Alarm:</b> Contact certified technician and inform of alarm failure condition. The technician must perform all repairs and testing prior to clearing the alarm condition. Record alarm condition and any tests/repairs in Attachment I.</p>	<p>Check the CAS ball valve positions and the ball valve near the ISD pressure sensor</p> <p>Exhibit 14- Clean Air Separator            TP-201.1E- P/V Valve            TP-201.1C or TP-201.1D-Drop Tube integrity test.            TP-96-1- 10 inch Pressure Decay            Exhibit 13 (Incon)</p> <p>Visually inspect hanging hardware at the affected dispenser(s) including;</p> <ol style="list-style-type: none"> <li>Replacing any damaged or worn face seals</li> <li>Repair or replace any misaligned face seals</li> <li>Replace any damaged or torn boots</li> <li>Tighten any loose boot clamps</li> <li>Replace any damaged or loose spouts</li> </ol>
<b>Pressure Alarm (Overpressure)</b> <b>Veeder Root</b> -ISD Gross Pressure Failure <b>Incon</b> -Weekly Ullage Pressure Failure	<b>Red</b> —Gross overpressure alarm failure on 8 <sup>th</sup> day after 7 day warning alarm		
<b>Degradation Pressure Alarm (Overpressure)</b> <b>Veeder Root</b> -ISD Degrnd Pressure Warning <b>Incon</b> -Monthly Ullage Pressure Warning	<b>Yellow</b> —Degradation overpressure alarm warning. Alarm will go to failure after 30 days.		
<b>Degradation Pressure Alarm (Overpressure)</b> <b>Veeder Root</b> -ISD Degrnd Pressure Warning <b>Incon</b> -Monthly Ullage Pressure Warning	<b>Red</b> —Degradation overpressure alarm failure on 31 <sup>st</sup> day after 30 day warning alarm.		

Alarm Condition- ISD Display Message	Indicator Light and Alarm Condition	Alarm Response	Tests/Inspections
<b>Collection Alarm</b> <b>Incon</b> -Daily Vapor Collection Fueling Pt Warning	<b>Yellow</b> —Collection alarm warning. Alarm will go to failure after 1 day.	Contact certified technician and inform of alarm warning condition. <b>This alarm must be cleared by a certified technician</b> unless the ISD self clears. . Record alarm condition and any tests/repairs in Attachment I.	
<b>Collection Alarm</b> <b>Incon</b> - Daily Vapor Collection Fueling Pt Failure	<b>Red</b> — Collection alarm failure on 2nd day after 1 day warning alarm	<b>This alarm must be cleared by a certified technician only.</b> Contact certified technician and inform of alarm failure condition. The technician must perform all repairs and testing prior to clearing the alarm condition. Record alarm condition and any tests/repairs in Attachment I.	Visually inspect hanging hardware at the affected dispenser(s) including; Replace any damaged or torn boots Exhibit 5, Option 1 of VR-204-X Exhibit 6, TP 201.4 Methodology 1 Exhibit 19 (Incon)
<b>Vapor Processor Input</b>	<b>Warning Only</b> Processor run time exceeds 62 continuous minutes or processor is shutoff or input to ISD console is disconnected.	<b>This alarm must be cleared by a certified technician only.</b> Contact certified technician and inform of alarm condition. The technician must perform all repairs and testing prior to clearing the alarm condition. Record alarm condition and any tests/repairs in Attachment I.	Exhibit 13 of VR-204-X