S131 - Ti-2, Shielded Metal Arc Welding (SMAW) Welding Process Emission Factors

Γ

CALCULATION METHODS Annual Emissions: Ea = Ua x EF (lbs/lb rod) x (1-e) Hourly Emissions: Eh = Uh x EF (lbs/lb rod) x (1-e) Ea = Annual emissions of each listed toxic air contaminant per welding rod, (lbs/year) Eh = Maximum hourly emissions of each listed toxic air contaminant per welding rod, (lbs/hour) Ua = Annual usage of each welding rod, (lbs/year) Uh = Maximum hourly usage of each welding rod, (lbs/hour) EF = Emission Factor (lbs/lb rod)								
Hourly Emissions: Eh = Uh x EF (lbs/lb rod) x (1-e) Ea = Annual emissions of each listed toxic air contaminant per welding rod, (lbs/year) Eh = Maximum hourly emissions of each listed toxic air contaminant per welding rod, (lbs/hour) Ua = Annual usage of each welding rod, (lbs/year) Uh = Maximum hourly usage of each welding rod, (lbs/hour)								
Eh = Maximum hourly emissions of each listed toxic air contaminant per welding rod, (lbs/hour) Ua = Annual usage of each welding rod, (lbs/year) Uh = Maximum hourly usage of each welding rod, (lbs/hour)								
Eh = Maximum hourly emissions of each listed toxic air contaminant per welding rod, (lbs/hour) Ua = Annual usage of each welding rod, (lbs/year) Uh = Maximum hourly usage of each welding rod, (lbs/hour)								
Uh = Maximum hourly usage of each welding rod, (lbs/hour)								
FF = Fmission Factor (lbs/lb rod)								
EF = Emission Factor (lbs/lb rod)								
Emission Factors: (1) Complete AP-42 information from Final Section 12.19 (1/95): EF = Trace Metal EF (Table 12.19-2)								
(2) Incomplete AP-42 Final Section 12.19 (1/95): $EF = FGR$ (Table 12.19-1) x FCF x Ci (MSDS)								
(3) No AP-42 information but known welding process: EF = FGR (District Default) x FCF x Ci (MSDS)								
(4) District Study or AWMA information: EF = Trace Metal EF								
(5) Incomplete District Study information: EF = FGR (District Study) x FCF x Ci (MSDS)								
(*) Incomplete AP-42, District, or AWMA Hexavalent Chromium information: EF = Cr (Total Chromium in Fumes) EF x HCR								
NOTES: • Emission factors assume "uncontrolled" releases. Emission control methods and efficiencies reported are be applied within the emission calculations.								
 Funds and encloses reported are de applied within the emission calculations. Fund generation rates (FGR) are based on the following: 								
o/EPA AP-42 Final Section 12.19 (1/95) Table 12.19-1 (PM10 EF)								
o ARB, Richard Bode: 0.01 (GMAW, TIG, MIG), 0.02 (SMAW, FCAW), 0.00005 (SAW), 0.05 (unspecified)								
• Fume Correction Factors (FCF) per District engineering discussions with Industry:								
ol0.5464 (GMAW, TIG, MIG), 0.2865 (SMAW, FCAW, SAW), 1.0 (unspecified)								
• Trace metal emission factors are based on the following:								
o AWMA Volume 59, 2009, Issue 5 (Pages 619-626) Table 2 and Table 3 o EPA AP-42 Final Section 12.19 (1/95) Table 12.19-2								
o District engineering estimates using rod compositions (Ci) from MSDS								
• Hexavalent chromium conversion rates (HCR) are per District engineering reviews of studies on welding:								
o [0.05 (GMAW, TIG, MIG), 0.55 (SMAW), 0.0005 (SAW), 0.10 (FCAW, unspecified)								
POLLUTANT DISTRICT EMISSION FACTORS (lbs/lb rod) REFERENCE DOCUMENT FACTOR (UNITS) C	COMMENTS							
NOX O								
СО								
SOX								
TOG								
VOC								
TSP 2.00E-02 Assu	ume PM10 = TSP							
CARB Welding Recommendations	me PM10 = Fume							
2.00E-02 (1993) 0.02 lbs/lb rod Gener	ration Rate (FGR)							
PM10 (1773) Oction	· · ·							
AI								
AI								
Al								
Al2O3								
Al2O3 Be Be								
Al2O3								
Al2O3 Be								

r	T		1	I	h	
Cr						
Cr(VI)						
Cu						
Mn						
Ni						
Р						
Pb						
Crystalline Silica						
v						
v						
Zn						
REFERENCES:						
EPA AP-42 Chapter 12.19: https://www.epa.gov/sites/production/files/2020-11/documents/c12s19.pdf AWMA: https://www.tandfonline.com/doi/abs/10.3155/1047-3289.59.5.619						

Last Updated on 07/07/2022 by A.Weller